




Polaroid S10 Dislodging the battery Replacement

Prerequisite only

Written By: Christofer





TOOLS:

- [Metal Spudger Set](#) (1)
-

Step 1 — Removing the backcover



- Place an opening pick between the volume button and the back cover.
- i* More than one pick may be needed but avoid placing more than two in the space.
- !* Excessive force on the pick will break the volume button.
- Carefully use the metal spundger to remove the back cover.
- i* A plastic snap noise is normal due to the tabs on the back cover.

Step 2 — Dislodging the battery



- Use spundger tool carefully remove the tape nearest to the battery.
- !* Use caution while removing tape, too much force can damage the device.
- Gently use the spunder to remove the battery out of place by wedging it from the bottom.
- !* Do not move the battery, it could cause the cables to be ripped out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-19 12:01:35 PM.